

## High Accuracy Digital Temperature/Humidity Sensor for DewMaster PEG-SENS-DEWMSTR

Thank you for choosing our product

This sensor is <u>only</u> compatible with the Pegasus Astro - DewMaster





## **Operating Instructions:**

- Plug the external environmental sensor to the RJ12 (sensor) socket.
- Device will produce a beep sound (after 5-10 seconds). This indicates that the sensor was discovered by the controller.
- Temperature and humidity readings will be displayed on the screen

## **Technical Specification**

- Cable plug: RJ 6P4C
- Relative Humidity Accuracy ±3% (typical)
- Temperature Accuracy ±0.2°C (typical)