



Double Riser 25 installation

- 1. Assemble two PEG-RISER-25 with the provided Counterbore M6 Bolts
- 2. Use the two provided M6 Countesunk bolts to seccurely mount Double PEG-RISER Assembly to Riser Slots depending on the telescope ring distance (Adjustable from 315mm to 127mm)

| | | | | |
|--------------|---------------------|---|-----------------|---------------|
| Dept. R&D | Technical reference | Created by GEORGE KARANTZALOS 17/10/25 | Approved by | |
| | | Document type | Document status | |
| | | Title Double PEG-RISER Assembly instructions | DWG No. | |
| | | | Rev. | Date of issue |
| | | | Sheet 1/1 | |